

PTZ PRO 2

Setup Guide | 设置指南




logitech 罗技™

3 ENGLISH


8 简体中文

KNOW YOUR PRODUCT




Camera

1. 10X lossless zoom
2. Camera LED
3. Kensington® Security Slot



Remote


4. Mirror
5. Zoom in
6. Pan and tilt
7. Zoom out
8. Camera presets 1, 2, and 3
9. Video mute
10. Far end control
11. Home
12. Remote battery door



Accessories

13. Camera mount
14. Cable lock
15. Cables

SET UP YOUR PRODUCT



1. Set up camera by placing on table or by using camera mount on table or wall.
2. Attach cable lock before plugging the cable into the camera port.
3. Connect to external power.
4. Connect the USB cable to your computer.
5. The camera LED will flash when the camera is connecting. Once complete, the camera head will rotate.
6. If the camera cannot connect, try again. If issues persist, consult www.logitech.com/support/ptz2 or call technical support.
7. Start your video call from your application. The camera LED will illuminate when streaming.

VISIT PRODUCT CENTRAL

Discover your product's full potential. Get valuable information and usage tips by browsing easy-to-use FAQs. Find answers to product questions and get help setting up your product. See if there's software available for download that can enhance your product experience.

To enjoy all the benefits of your Logitech product, visit **www.logitech.com/support/ptz2** and take advantage of Logitech's wide range of useful support services.

- Troubleshooting
- Diagnostics
- Firmware upgrades
- Support community
- Software downloads
- In-box documentation
- Warranty information
- Spare parts (if available)

USE YOUR PRODUCT

Video


- **Starting the video:** Video will start once a video call/capture session is opened and the camera is selected. The camera LED will illuminate when the video is streaming.
- **Pan and tilt** the camera using the remote control. Press once for incremental movement or press and hold for continuous pan or tilt. Caution: Do not manually rotate webcam head. Doing so may damage unit.
- **Zoom** the camera up to 10X by pressing the zoom button.
- **Home:** Press the Home button to return to the default, out-of-box home position.
- **Camera presets:** You can set up to 3 preset positions. First, position the camera using the pan and tilt controls, and then press and hold one of the preset buttons for 3 seconds to save that position. You may return to your defined position at any time by pressing the preset button once.

Use Preset 1 as your own defined “home” position. When the camera is reconnected to the PC, it will return to the position set in Preset 1. If no position is set for Preset 1, the camera will return to the default home position.

All three presets are by default set to the out-of-box home.

- **Far end control:** This function allows you to control the pan, tilt, and zoom of any remote Logitech ConferenceCam or select Logitech Webcams. Some applications support this feature natively, while others can be enabled by using an application downloaded from **www.logitech.com/support/ptz2**. Please visit the download page listed for more information.
- **Camera settings application:** You can use this program to control the pan, tilt, zoom, focus, and image quality (like brightness and contrast) of the camera from your computer. This application can be downloaded from **www.logitech.com/support/ptz2**.

Mounting your camera






Changing the remote control battery

The PTZ Pro 2 remote control runs on a Li-ion CR2032 battery. Battery life will vary based on usage.

TROUBLESHOOTING TIPS

Please visit www.logitech.com/support/ptz2 for troubleshooting tips, information on software tools, and for a diagnostic tool to help troubleshoot issues you may have with your PTZ Pro 2.

了解您的产品



摄像头

1. 10X 无损变焦
2. 摄像头指示灯
3. Kensington® 防盗锁插孔

遥控


4. 镜像
5. 放大
6. 水平与垂直摄像
7. 缩小
8. 摄像头预置 1、2 和 3

9. 视频静音
10. 远端控制
11. Home
12. 遥控器电池盖

配件

13. 摄像机底座
14. 线缆锁
15. 线缆

设置您的产品



1. 将摄像头置于桌子上，或通过摄像头底座将摄像头支在桌子或墙上。
2. 将线缆插入摄像头端口前，先安装线缆锁。
3. 连接外部电源。
4. 将 USB 连接线连接到计算机上。
5. 摄像头指示灯闪烁，表示正在连接。连接成功后，摄像头旋转。
6. 如果无法连接摄像头，请重试。若仍存在问题，请咨询 www.logitech.com/support/ptz2 或致电技术支持。
7. 通过应用程序启动视频通话。播放时，摄像头指示灯将亮起。

访问产品中心

全面发掘产品潜力。请浏览常见问答集,了解相关的实用信息和技巧。查询有关产品问题的答案及产品安装帮助。查看是否有软件可供下载,提升产品体验。

如需尽享罗技产品的各种优势,请访问 www.logitech.com/support/ptz2, 充分利用罗技体贴周到的支持服务。

- 故障排除
- 诊断
- 固件升级
- 支持社区
- 软件下载
- 包装盒内文件
- 保修信息
- 备用部件 (若有供应)

使用您的产品

视频


- 观看视频：启动视频电话/拍摄并选择了摄像头之后，视频将立即开始。视频播放时，摄像头指示灯亮起。
- 使用遥控器可上下左右移动调整摄像头。单次按下可进行增量移动调节，按住不放可连续进行上下左右调整。注意：请勿手动旋转网络摄像头。否则可能损坏设备。
- 按下缩放键，可实现摄像头 10X 变焦。
- Home：按下 Home 按键可返回出厂设置的默认原位。
- 摄像头预置：最多可设置 3 个预置位置。首先，通过控制装置确定摄像头位置，之后按住其中一个摄像头预置键 3 秒钟以保存该位置。按下预置按钮，可随时恢复到自定义位置。

将预置 1 自定义为“原位”。当摄像头重新连接至 PC 时，将返回至预置 1 所设置的位置。如果预置 1 未设置位置，摄像头将返回至默认原位。

所有三个预置默认均设置为出厂原位。

- 远端控制：该功能允许您控制任意远程罗技视频会议系统或指定罗技网络摄像头的平移、倾斜和变焦。某些应用本身便支持此功能，其他应用则可以借助从 www.logitech.com/support/ptz2 下载的应用程序加以实现。请访问下载页面查看更多信息。
- 摄像头设置应用程序：您可以使用此程序控制您电脑摄像头的平移、倾斜、变焦、聚焦和图像质量（比如亮度和对比度）。此应用程序可从 www.logitech.com/support/ptz2 下载。

安装摄像头



更换遥控器电池

The PTZ Pro 2 遥控器使用 CR2032 锂离子
电池。电池寿命依使用情况而异。

故障排除技巧

请访问 www.logitech.com/support/ptz2
查看故障排除技巧、软件工具信息及诊
断工具, 以帮助您解决 PTZ Pro 2 的相关
问题。

© 2017 Logitech. Logitech, 罗技, Logi and other Logitech marks are owned by Logitech and may be registered. All other trademarks are the property of their respective owners. Logitech assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

版权所有 © 2017 年罗技。罗技、Logi 和其他罗技商标均归罗技所有，并或已注册。所有其它商标均是各自所有者的财产。罗技对于本手册中可能出现的任何错误不承担任何责任。本手册中包含的信息如有更改，恕不事先通知。

WEB-621-001010.002